

CARAVELLE CROSS - BASIN SET

WATER EFFICIENT TAPWARE

PLUMBERS INSTALLATION INSTRUCTIONS

Important Information

- * Not suitable for gravity feed systems.
- * Swivel basin outlet is fitted with a flow regulated aerator insert. This low flow rate may not be suitable for connection to some Instantaneous Gas Water Heaters, some Tempering Valves, some Solar Water Heaters & some Thermostatic Mixing Valves. Check with the manufacturers of these products.
- * Isolating stop taps are recommended to be fitted to the inlet connections.(Part No: 842018C - Mini cistern 1/4 T)
- * 3 handles are provided to indicate cold, hot & tempered water supplies. Discard the handle not required.
- * All pipework must be thoroughly flushed prior to installation, as foreign materials may block the flow regulating device and reduce the flow of water. Note: Aerator insert housing must be retightened to prevent removal by hand.

Installation

200mm 175mm 150mm

- 1) Measure centre distance between tap body holes in deck, cut breech piece (16) to required length. (As a guide see cutting template below)
- 2) Install basin outlet (20) with seal (19), ensuring screw is at the back. Fit washer (18) and backnut (17) and tighten.
- 3) Fit compression nuts (15) and olives (14) to each end of breech piece (16), connect to tap bodies (13) and tighten compression nuts (15) slightly.
- 4) Fit one locknut (11) and one washer (12) to each tap body (13). Install assembly into deck ensuring "O" rings on breech piece (16) are not damaged as they enter tail of basin outlet (20). Fit remaining washer (12) and locknut (11), adjust locknuts (11) so that the tap bodies (13) protrude 5mm above the deck and tighten.
- 5) Tighten compression nuts (15) on the breech piece (16).
- 6) Remove locknut (8), cap (9) and fibre washer from cartridge (10). Screw cartridge (10) into tap body (13). Using a suitable spanner, tighten cartridge (10) until it comes to a firm stop. (DO NOT TIGHTEN CARTRIDGE USING SPINDLE) Fit fibre washer and then locknut (8) and tighten using a suitable spanner.

IMPORTANT

Pressure & Temperature Requirements.

- Hot and cold water inlet pressures should be equal.
- Static inlet pressure range: 150 -1000 kPa New Regulation: 500 kPa maximum static pressure at any outlet within a building. (Ref. AS/NZS 3500.1)
- Maximum hot water temperature : 80°C.


Deck Requirements

- Centre distance between tap body holes:120-210mm
- Deck thickness: 25mm maximum
- Tap body holes (in deck) : Φ34-36mm
- Tap outlet hole (in deck) : Φ22-30mm
- 7) Screw on flanges (6) to each locknut (8) and tighten securely by hand, taking care not to damage decorative finish.
- 8) Fit handle assembly as follows:-
- i) Turn both spindles (7) to the fully closed position.
- ii) Place retaining nut (4) over spindle (7), with slot facing down.
- iii) Fit retaining clip (3) into groove at bottom of spline in spindle (7).
- iv) Ensure handle insert (2) is in position in handle (1). Fit handle (1) to spline of spindle, position handle to suit then push firmly down until it bottoms internally. Note: Water supplies are indicated by the following handle colours. Blue = Cold. Red = Hot. Yellow = Tempered. Discard the handle not required.
- v) Screw retaining nut (4) into handle and tighten with spanner (5) provided.

Removing Aerator Insert

- 1) Carefully remove aerator housing (21) from basin outlet (20), taking care not to damage the decorative finish.
- 2) Remove 'O'Ring (23) & aerator insert (22) from aerator housing (21) Check that aerator housing (21) is clean. Deposits of lime can be removed by washing in a vinegar solution.
- 3) Fit aerator insert (22) into aerator housing (21) followed by 'O'Ring (23) then screw assembly into basin outlet (20) and tighten securely (to prevent removal by hand).





16

20

15

Fig.1

Cut to suit measured centre distance in basin top

140mm

BREECH PIECE

IS1713A(08/17)

Fibre Washer