 INSTALLATION INSTRUCTION FOR OVERMOU Inspect sink for damage and dimensional compatibility. Doinstall a damaged sink. Using the cut-out template mark the exact location of the the benchtop and draw a pencil line against the edge of the sect to part of the desired fit. Before commencing cutting, double check the marked cut out the bench top carefully following the inside edge of the exact cut is required to obtain the best fit. For normal thickness bench tops, the attached fixing clips Lightly hammer the fixing clips onto the clip brackets at eaproduct rim.(If the thickness of the bench top exceeds the clips then extension clips can be purchased and mounted brackets. See Figure B) Position the sink in the cut out hole and align properly. The bent out of the way to assist installation (see Figure C). Che sealing tape will seal evenly around the edge of the hole. Remove the sink and if required install the waste assemblic suggested that silicone sealant be applied between the way sink outlet hole. Remove the protective backing from the sealing tape, app of silicone sealant between the sealing tape and the edge quickly place into position. Bend the fixing clips straight so that the legs clear the hing clips evenly using a low torque setting (see Figure D). Note clip may strip the thread. Plumb up the tap and waste fittings.

Evolution Care 1.5 End Bowl Sink 4070



