

CAROMA CONTURA II - UPSWEPT SHOWER ARM



PLUMBERS INSTALLATION INSTRUCTIONS

Important Information

- * All pipework must be thoroughly flushed prior to installation.
- * Where showers incorporate flow controllers, care must be taken during installation to ensure that the male connecting threads do not damage flow controllers.

Installation

- 1) Check that threaded nipple (1) is the correct length, as shown. Cut to length if required ensuring end face is square. Apply thread tape to the thread.
Important : Care must be taken that thread tape cannot become dislodged and block the flow regulating device (when fitted), causing a reduction in water flow.
- 2) Screw adaptor (2) onto threaded nipple (1) until adaptor (2) is held securely against wall/tile face. **DO NOT OVERTIGHTEN**. Apply suitable lubricant to 'O'Rings on adaptor (2).
- 3) Ensure screws (4) are wound out in the wall body (3). Carefully slide the wall body (3) onto the spigot of adaptor (2), taking care not to damage the 'O'Rings on the spigot. While holding the body against the wall with the arm (6) vertically aligned, tighten the grub screws (4) using the 2.5mm allen key (5).
- 4) When installing the shower head (8) onto the connection thread (7) of the shower arm (6), refer to the individual instructions supplied with the shower head.



IMPORTANT

Pressure & Temperature Requirements.

- Hot and cold water inlet pressures should be equal.
- Inlet pressure range : 150 -1000 kPa
New Regulation:- 500 kPa maximum static pressure at any outlet within a building. (Ref. AS/NZS 3500.1)
- Maximum hot water temperature : 80°C.